



**Pacific Northwest**  
NATIONAL LABORATORY

*Proudly Operated by **Battelle** Since 1965*

# **Management of Time Sensitive Reactive and Unstable Chemicals**

**Presented by:**

**Andrew Minister, PE**

**Chief Fire Protection Engineer**

**Pacific Northwest National Laboratory**

NATIONAL FIRE PROTECTION ASSOCIATION  
2013 CONFERENCE & EXPOSITION  
McCORMICK PLACE CONVENTION CENTER  
CHICAGO, ILLINOIS  
JUNE 10, 2013



## **\*\* Disclaimer \*\***

In the course of this presentation, any comment as to the “meaning” of any part of any NFPA code or standard is only the opinion of the presenter and is NOT to be relied upon as either accurate or official. Only the NFPA may issue a formal interpretation of its codes and standards.

This presentation is not on behalf of any vendors or their products.

# Management of Time Sensitive Reactive and Unstable Chemicals

## OBJECTIVES

- ▶ Define categories of time sensitive reactive and unstable chemicals
- ▶ Understand how these chemicals become reactive or unstable over time and to know what has happened when these chemicals are not properly managed
- ▶ Learn how to store and effectively manage these chemicals to prevent emergency situations

# Management of Time Sensitive Reactive and Unstable Chemicals

## Headlines from Recent Events

- ▶ 'Overpressurized' container bursts in Wetherill, sends students to hospital – 02/22/11 
- ▶ School Evacuated As Bomb Squad Deals With Unstable Chemical – 07/09/11 [Unstable Chemical](#)
- ▶ Evacuation After Chemical Explosion At Bedford Park – Australia – 07/30/12
- ▶ Army Team Makes Safe Unstable Chemicals at Dundalk IT – Ireland – 10/07/12 [Celloidin wool](#)
- ▶ Unstable Chemical Forces UC San Diego Evacuation – 11/09/12 

## Time Sensitive Chemicals

- ▶ Time sensitive chemicals have the special ability to become significantly more hazardous during storage
- ▶ Peroxide forming chemicals
- ▶ Chemicals that become unstable reactive upon depletion of inhibitor
- ▶ Chemicals that are explosive when dry
- ▶ Gases that are corrosive to their cylinders

## Hazards Associated with Time Sensitive Chemicals

- ▶ Peroxide forming chemicals may explode when moved; heated; or exposed to light, shock or friction
- ▶ Auto-polymerization may occur in unstable chemicals with rapid heat release and pressure buildup resulting in violent container rupture or explosion
- ▶ Fire and/or explosion when chemicals dry out
- ▶ Gas cylinder rupture with release of corrosive gas

## Management of Time Sensitive Chemicals

- ▶ Establish procedures for management of all chemicals with an emphasis on time sensitive chemicals
  - Identify chemicals and products that present a time sensitive hazard
  - Control procurement of these chemicals
  - Establish procedures for storage of these chemicals
  - Have a defined disposal process for these chemicals prior to procurement
  - Train users on the management of these chemicals

## Management of Time Sensitive Chemicals

- Establish a process for tracking these chemicals
  - Know where they are located
  - Date containers when received
  - Dates when the chemicals have been inspected
  - Discard chemicals prior to their expiration date
- Appropriate storage conditions for each chemical
- Plans to address chemicals that may be hazardous or unsafe
  - Testing for hazards (when possible)
  - Establish action levels for treatment
  - Always test liquids for peroxides before distillation

## Peroxide Forming Chemicals

- ▶ Four categories of peroxide formers
  - Chemicals that form explosive levels without concentration (most dangerous)
  - Chemicals that form explosive levels upon concentration
  - Chemicals that may autopolymerize as a result of peroxide accumulation
  - Chemicals that form peroxides but don't fit in the other categories



Source: Kelly, Richard J., *Review of Safety Guidelines for Peroxidizable Organic Chemicals*, Chemical Health & Safety, September/October 1996 Volume 3 Number 5

## Peroxide Forming Chemicals

- ▶ Form light, heat and/or shock sensitive peroxides and peroxide compounds
- ▶ Controls to prevent peroxide formation
  - Dark colored glass bottles or steel cans
  - Inert cover gas over liquid to minimize availability of oxygen to form peroxides
  - Inhibitor added to stabilize chemical and prevent peroxide formation
  - Storage time since opening of the container

## Peroxide Forming Chemicals

### ▶ Examples

- Acrolein
- Ethers – ethyl ether, isopropyl ether, others
- Tetrahydrofuran (THF)
- Vinyl acetate
- Secondary alcohols – 2-propanol (isopropyl alcohol), 2-butanol (butyl alcohol)
- 1,3-Butadiene – gas

## Peroxide Forming Chemicals

### ► Identification

#### ■ MSDS statements

- May form explosive peroxides upon prolonged storage
- Avoid contact with light
- May contain peroxide inhibitors
- Do not evaporate or distill to dryness
- Store in a tightly closed container
- Stabilized with hydroquinone

## Peroxide Forming Chemicals

### ▶ Key Management Controls

- Understanding proper storage requirements
- Understanding rate of peroxide formation and how the inhibitors control the rate of formation
- Define the inspection frequency for each chemical and track in a database
- Visually inspect container before handling for signs of peroxide formation
- Test before distillation; distillation concentrates peroxides, if present, and removes inhibitors

# Management of Time Sensitive Reactive and Unstable Chemicals

## Peroxide Forming Chemicals

### ▶ Key Management Controls

- Know how to test for peroxide level

- No test method is 100% accurate

- Dip test strips – available in several ranges from most lab supply companies, fastest test method

- ◆ Limitations – may not detect poly-peroxides, may not work with non-solvent liquids, shelf life

- Solution tests – add solutions to sample of chemicals to see if peroxides are present

- ◆ Potassium iodide – not as accurate as strips

- ◆ Ferrous thiocyanate – complex test

## Chemicals That Become Unstable Reactive Upon Depletion Of Inhibitor

- ▶ May polymerize when the inhibitor is depleted
- ▶ Most are also peroxide formers
- ▶ Classified as “unstable reactive” Class 2 chemical when stabilized – Class 4 without a stabilizer
- ▶ Types of chemicals
  - Acrolein
  - Vinylic monomers such as styrene, divinylbenzene, methyl methacrylate, vinyl acetate
  - 1,3-Butadiene – gas

## Polymerization Event Involving Unstable Reactive Chemicals

- ▶ Styrene Release in Cincinnati in 2005 [Styrene Event](#)
  - Railroad tank car was on the tracks for several months and was left on rail siding for more than a month
  - The styrene had stabilizer for 2-4 months
  - There were high temperatures in August
  - Evacuation for ½ mile
  - Closed nearby airport – in flight path
  - PRV vented gas safely
  - Tank car cooled by fire department hose streams

## Chemicals That Become Unstable Reactive Upon Depletion Of Inhibitor

### ► Identification

#### ■ MSDS statements

- Avoid loss of dissolved air, loss of inhibitor, and contamination with incompatible materials
- Explosive polymerization will only occur if material does not contain an inhibitor (stabilizer)
- Shelf life is dependent on storage temperature and inhibitor level
- Recommended storage temperature: 2 - 8 °C
- Container may rupture from polymerization

# Management of Time Sensitive Reactive and Unstable Chemicals

## Chemicals That Become Unstable Reactive Upon Depletion Of Inhibitor

### ► Key Management Controls

#### ■ Understanding storage requirements

- Storage temperatures critical to consumption of inhibitor
- Shelf life – follow manufacturers recommendations
- Know what chemical is used to inhibit polymerization – add as needed to store safely
- Most require oxygen for inhibitor to work – may require stirring to keep oxygen dissolved in product
- Dispose of chemicals when outdated or no longer needed

# Management of Time Sensitive Reactive and Unstable Chemicals

## Chemicals That Are Explosive When Dry

- ▶ Chemicals are usually wetted with a solvent or water
- ▶ Wetted with 25% or more liquid
  - Some explosives are shipped as flammable liquids if they are wetted with 25% or more in a solvent
- ▶ Types of chemicals
  - Acetyl peroxide in dimethyl phthalate
  - Flexible collodion (nitrocellulose)
  - Picric acid
  - Urea nitrate



## Chemicals That Are Explosive When Dry

### ► Identification

#### ■ MSDS statements

- Do not allow this material to dry out
- Maintain at least 20% water content to minimize explosive potential
- May explode spontaneously in storage
- Very unstable if allowed to dry completely

### ► Storage

- Keep containers tightly closed
- Segregate from incompatible chemicals

# Management of Time Sensitive Reactive and Unstable Chemicals

## Chemicals That Are Explosive When Dry

### ▶ Key Management Controls

- Establish an inspection frequency to verify wetting of chemical
- Add additional wetting agent to keep minimum wetted concentration
- Dispose of chemical when not longer needed or prior to expiration date

## Gases That Are Corrosive To Their Cylinders

- ▶ Gases that chemically react with the metal walls of the cylinders that they are stored in
- ▶ Lecture bottle size cylinders are the biggest hazard
- ▶ Types of chemical gases
  - Hydrogen bromide
  - Hydrogen chloride
  - Hydrogen fluoride
  - Tungsten hexafluoride

# Management of Time Sensitive Reactive and Unstable Chemicals

## Corrosive Gas Cylinder Hazard



Damage in lab



- Old Hydrogen Fluoride  
Cylinder

## Gases That Are Corrosive To Their Cylinders

### ▶ Key Management Controls

- Buy gas cylinders that can be returned to the manufacturer
- Return the gas cylinders to the manufacturer before the date when they will no longer accept them
  - NFPA 45 A.11.1.2 Cylinders of hydrogen fluoride and hydrogen bromide should be returned to the supplier within 2 years of the shipping date.

# Management of Time Sensitive Reactive and Unstable Chemicals

## Time Sensitive Chemicals

### ▶ Key Management Controls

- If one of these types of chemicals becomes hazardous, get professional help.
- If your company/organization uses these types of chemicals, know who to contact for help before you need assistance.

### ▶ Other Types of Time Sensitive Chemicals

- Gas forming – calcium carbide forms acetylene; chloroform forms phosgene
- Alkali metals – can form superoxides
- Others – see references and resources

## References and Resources

- ▶ CRC Handbook of Laboratory Safety – 5<sup>th</sup> Ed.
- ▶ Handbook of Chemical Health and Safety
- ▶ National Research Council - Prudent Practices in the Laboratory (2011 edition)
- ▶ Richard J. Kelly *Review of Safety Guidelines for Peroxidizable Organic Chemicals*, Chemical Health & Safety, September/October 1996 Volume 3 Number 5
- ▶ NFPA 45 Standard on Fire Protection for Laboratories Using Chemicals
- ▶ Peroxides: <http://www.ilpi.com/msds/ref/peroxide.html#further>

## References and Resources

- ▶ Management of time sensitive chemicals (I):  
Misconceptions leading to incidents:  
[http://www.hss.energy.gov/healthsafety/wshp/chem\\_safety/Self\\_Assess/manuscript1.pdf](http://www.hss.energy.gov/healthsafety/wshp/chem_safety/Self_Assess/manuscript1.pdf)
- ▶ Management of time-sensitive chemicals (II):  
Their identification, chemistry and management:  
[http://www.hss.energy.gov/HealthSafety/WSHP/chem\\_safety/Self\\_Assess/manuscript2.pdf](http://www.hss.energy.gov/HealthSafety/WSHP/chem_safety/Self_Assess/manuscript2.pdf)
- ▶ Management of time-sensitive chemicals (III):  
Stabilization and treatment:  
[http://www.hss.energy.gov/HealthSafety/WSHP/Chem\\_Safety/Self\\_Assess/Time\\_mgmt3\\_rev\\_2af.pdf](http://www.hss.energy.gov/HealthSafety/WSHP/Chem_Safety/Self_Assess/Time_mgmt3_rev_2af.pdf)

# Management of Time Sensitive Reactive and Unstable Chemicals

## QUESTIONS?



Andrew Minister – [andrew.minister@pnnl.gov](mailto:andrew.minister@pnnl.gov)